SimpleCut   Read me

About SimpleCut

Thank you for purchasing a Mimaki product.
SimpleCut is a cutting software which offers simple operation and stable cutting enviroment.
SimpleCut supports Windows.

For details, please refer to the operation manual.

System Requirements

To install and use SimpleCut,the following conditions must be met.

OS	Windows Vista / XP / 2000 / 7 / 8
PC	Equivalent to Pentium Celelon 1 GHz processor or higher
Memory	256MB or more
HDD	500MB or more free space
Scanner	Support for TWAIN driver
Monitor	Minimum resolution 1024 * 768 pixels or more
Plotter	Mimaki (CG-FX serise,CG-75ML,CG-60st,CG-60SR, CG-60SL,CG-SRII serise,CG-SRIII serise)

Notice

1. When execute setup of SimpleCut, PDF format of Operation manual is copied to hard disk.
   To read this manual, "Adobe Reader" is required. If "Adobe Reader" is not installed on your computer,
   please install "Adobe Reader" in this CD-ROM.

2. "Mimaki USB Driver" in this CD-ROM is required when using a USB port with Mimaki CG-FX/75ML/60SL
   /60SR/SRII/SRIII plotter. In the case of using a CG-60st, installation is not necessary.
   In addition, "Mimaki USB Driver" doesn't correspond to "Windows XP Professional x64 Edition".

3. It is strictly prohibited to copy this software to other disk (excluding the case for making backup) or
   to load on the memory for the purpose other than executing it.

4. With the exception of what is provided for in the warranty provisions of Mimaki Engineering Co.,Ltd.
   We do not assume any liability against the damages (including but not limited to the loss of profit,
   indirect damage, special damage or other monetary damages) arisen out of the use or failure to use of
   notified of the possibility of arising damages in advance. As an example, we shall not be liable for
   any loss of the media (works) made using this product or indirect damages caused by the product made
   using this media.

We hope you will continue to patronize Mimaki products.